

mamava®

Pop-up Lactation Pod

User Guide



We're pumped to provide this Mamava lactation pod for your event. Thanks to partners like you, we're closer to creating a future where there is a dignified space to pump or nurse anywhere a parent may go—including at your event!

Usage Terms

- Renter provides electrical source, chair, and table inside each pod.
- Because of the pod's open top, it must be placed in a covered area for privacy from overhead views.
- Mamava Inflatables are NOT intended to be permanent structures and are not designed for outdoor use unless specifically approved by Mamava. If outdoor use is approved, it is the renter's responsibility to place the pod under a tent and secure it to the ground. In the event of extreme weather conditions such as strong winds, heavy rain, snow, hail etc., the unit(s) should be deflated.
- Wet units should be allowed to dry while inflated before repacking in crates.



One blue crate includes

- Inflatable pod with fan attached
- Blue extension cord
- 3-plug yellow GFCI outlet
- Zip ties for repacking the crate
- Stakes for outdoor units
- Detailed instructions

Not included

- Table and chair


Setup

Open the crate by cutting the zip ties using a pair of scissors or a box cutter. Store the crate for return shipping.

1. Position. Remove the deflated pod and unroll it on a clean, flat surface. Set aside the 3-plug outlet and extension cord. Spread out the pod evenly so that the fan is unobstructed. Ensure the surrounding area is clear of obstacles and sharp objects.



2. Power. Plug the fan cord (black) into the provided 3-plug outlet (yellow). Plug the 3-plug outlet into the extension cord (blue), and plug the extension cord into your electrical source. The fan will start when plugged in and inflate the pod.



3. Inflate. Check that the fan remains unobstructed. As your pod inflates, it may need a hand to stand up until fully inflated. The pop-up will fully inflate in approximately two minutes. **Pod requires power to remain inflated**, but can be unplugged during off hours.



Furnishing and Usage

Comfort is key! Please provide parents with:

- A small table and a chair inside the inflated pod
- Rugs, pillows, snacks, water, tissues and wipes can help make the space extra inviting.

Power for their pump. Ensure the 3-plug outlet (yellow cord) is inside the pod and near the table and chair so parents can plug in their pumps easily.

Privacy. The pod door closes using strong magnets and can be easily guided shut once someone is inside. In addition, there are clips inside of the pod, on either side of the door, for added privacy. To open the door, run a hand down through the opening to release magnetic pull.



Return

Deflate. To deflate, simply unplug the fan. Make sure the fan remains clear so air can escape. Pod will fully deflate in approximately eight minutes. **Allow wet units to dry before you deflate.**

Pack. Place outlet and extension cord in the bottom of the crate. Once the pod is fully deflated, evenly fold it to the width of the crate. Tightly roll along its length, pushing out air until compact. Rolling the material around the fan helps protect the fan from being damaged in shipping.

Ship. Place instructions inside the crate. Secure the top of the crate using the provided zip ties. **Attach the provided UPS return label and bring it to your nearest UPS drop-off location.**