

mamava Owner's Manual

www.mamava.com

(802) 324-2111





hello

Mamava is committed to making breastfeeding
and pumping an authentic choice by providing spaces
for nursing parents.

Thank you for helping move our mission forward
and making the world better for breastfeeding.

Welcome to the family.

What to Know About Your Mamava Pod	3
Mamava App + Smart Access Technology	4
Alternate Pod Access	6
Keypad	7
Keys	8
Care + Keeping.....	10
Communications + Education.....	11
Troubleshooting Tips	14
Beyond the Pod Support	15

What to Know About Your Mamava Pod

Mamava pods are powered by one standard outlet.

The electrical cord extends a few feet from the unit. Route it to prevent cord damage and tripping. Inspect the cord regularly for signs of wear. If unplugged, the pod's lights, fan, and internal outlets won't work. Consider installing an outlet lock to prevent unauthorized people from unplugging the pod.

There are 3 ratings for the pods:

Branch Circuit: 120vAC / 20A / 2400W

Pod: 12vDC / 6.67A / 80W

Outlet: 120vAC / 13.33A / 1600W

Pods are intended for indoor use only.

The fans help circulate air by pulling it in from outside the unit, so place your pod in spaces serviced by HVAC.


Pods should be convenient for parents.

Place in an accessible spot—ideally near a restroom. Let Mamava know where your pod lives and if you move it in the future: fulfillment@mamava.com.

Pods need care and maintenance.

For service support, contact service@mamava.com, submit a form on our website, or call (802) 347-2111.

IMPORTANT: If you contact us about an issue with your pod, please have the serial number handy. The pod serial number is inside the door frame—on the top of the door jamb.



Mamava's Smart Access technology enables pod access via our app.

Mamava App + Smart Access Technology*



mamava
Lactation Pod



BENEFITS FOR POD USERS

Access

Open Mamava pods with the touch of a button. Like magic.

Wayfinding

Find pods and thousands of other lactation pods.

Occupancy

Check occupancy status and duration.

Vacancy alerts


Receive alerts when pods are available.

Words of support

Read encouraging notes from other breastfeeding parents.

Resources

Access virtual lactation consulting and helpful breastfeeding info.



BENEFITS FOR POD OWNERS

Usage reports

Customers who upgrade to a Service Plan for their Smart Access Mamava lactation pods gain access to metrics that provide insights into pod usage patterns.

*Not available on Solo Base pods.


Mamava's app makes for easy access, but pods can also open with keypad codes and keys.

Keypad

Pods can be unlocked using a four-digit keypad code. Locks come preprogrammed with five Mamava admin codes for app-enabled entry. (If the Bluetooth connection fails between the pod and a phone, an access code is served up to the user). Six slots remain for custom codes. Avoid adding more than six or that will override pre-programmed ones.

How to add or edit access codes

- 1 Download the Mamava for Business app in the App Store or Google Play, then create an account, or sign in.
- 2 Enable Bluetooth for the app and ensure you're standing outside the Mamava pod, within Bluetooth range. (If not, you'll get an error message when adding custom codes.)
- 3 Locate your pod or lock serial number. The pod serial number is on the sticker inside the door frame. (Use 2014# to open the door.) The lock serial number is on the key tag provided by Mamava. Need help? Contact service@mamava.com.
- 4 Input the serial number (pod or lock) in the "Enter Serial Number" field in the app.
- 5 To add a new access code, tap the "Create new code," enter a new four-digit numerical code, and then save.
- 6 To remove an access code, tap "Delete" next to the code you want to remove and confirm deletion when prompted.
- 7 To edit the maintenance code, tap "Manage," enter a new four-digit access code, and update.



*Not applicable to tech-free Solo Base pods, which have a keyless door handle (with an interior deadbolt).

Keys

Mamava pods also come with keys for alternate access or service visits. Store keys in a safe place.

Lock keys (2)

To access the keyhole, press down on the right side of the oval cover plate with the word “Port” on the top of the lock and remove it.

Emergency deadbolt key (1)

Insert the emergency deadbolt key into the center hole of the occupancy indicator dial and turn to “VACANT. Enter your code or “2014#” to open the door.



Lost keys?

If you lose your keys and **need to change the lock battery:**

Use the micro-USB cable (a generic cable included with pod delivery or available in stores) to provide temporary power to open the lock.

Note: This won't charge the lock as the provided batteries are not rechargeable.

Cable (supplied by Mamava)

External battery (supplied by pod owner)



Breastfeeding parents will appreciate this comfortable, private space for pumping and nursing. Especially if it's clean.

Care + Keeping



● Schedule regular cleanings

Place your Mamava pod on the same cleaning schedule as your facility bathrooms.

● Disinfect surfaces

Disinfect door handles, shelves, and seats.

● Clean the mirror

Use mild soap, Windex, or Zep All Purpose Cleaner. Avoid alcohol-based cleaning agents.

● Encourage parents to clean up

Communicate the importance of sanitizing hands and cleaning up spills to pod users.

● Vacuum fans

Vacuum both sides of the fan(s). The fans are capable of at least 35 ACH (Air Changes per Hour), but a dirty fan can reduce this air exchange rate. (To clean, go inside the pod—you'll see the fans above the roof pan.)


● Offer amenities

Place a trash can outside or near the unit—not inside. Consider supplying hand sanitizer and/or sanitizing wipes. Keep them stocked and refill as needed.

Find helpful pod information, resources, and assets: help.mamava.com.

Mamava has tips and tools to help parents find pods, educate your organization, and celebrate breastfeeding support.

Help Parents Find Your Pods



Moving your pod? Let us know!

Contact fulfillment@mamava.com and include photos of the pod in its new location so we can update the app.

Mamava app

Include your pod in our free app to highlight your support for breastfeeding parents and help ensure a more consistent experience for guests and/or employees.

TIP: If a parent doesn't see locations in the app, they may need to turn on location services in their phone's settings and/or turn off low power mode.




Restroom stickers

Place a decal outside of each women's or gender-neutral restroom so that parents know there's a designated space to pump or nurse that's not a bathroom.



Directional signage

Box signs, banners, and wall decals help breastfeeding parents find pods.



Communications + maps

Add the location of your Mamava pod(s) to facility maps, directories, and relevant communications with guests and/or employees.

Educate Internal Stakeholders

Mamava's **resource library** can help educate your organization about what breastfeeding parents need and provide **support and inspiration** for parents.

[View library](#)



Broadcast Your Breastfeeding Support

Templates and tips for ribbon cuttings, press releases, and social posts to communicate and celebrate your lactation support. (Mamava Marketing can help amplify.)

[View promotion kit](#)



Parents love to share on social media!

Clean and welcoming pods get lots of love. Dirty or out-of-order ones get frustrated call-outs. Be the hero breastfeeding parents need!

Use our at-a-glance guide for easy answers to FAQs. Find more information and helpful tips in Mamava's Help Center.

Mamava Support and Service

Self-serve support with our comprehensive [Help Center](#). For info about preventative maintenance and service plans contact sales@mamava.com.



Troubleshooting Tips

Parents can't open the pod with the Mamava app.

Make sure the pod is located where there is a Wi-Fi connection and/or data service available. Ensure that users are within three feet of the pod, have Bluetooth and location services turned on, and low power mode off.

Give breastfeeding parents a number to call (or a service desk to visit) if they have trouble getting into the pod. Visit help.mamava.com or email fulfillment@mamava.com for a sticker template.

Need help with access?

During business hours, call the information desk: 1-800-234-5677

If you're visiting between 9pm-6am, call: 1-800-234-5634

The lights and fan(s) don't turn on.

Locking the deadbolt powers the pod, so make sure the deadbolt is fully in the locked position. Make sure the pod's power cord is plugged in and the wall outlet is functioning properly. For technical assistance, contact service@mamava.com.

IMPORTANT! The 5A fuse that regulates the Pod Control Device needs to be replaced by a trained service professional, as designated by Mamava.

You need to relocate your pod.

Mamava pods have built-in caster wheels to move them short distances. For details about deploying the casters, see Assembly Instructions. If you want to move your pod to another building, across uneven floor surfaces, or need to store it, you'll find instructions on how to disassemble your pod at help.mamava.com.

REMINDER: If you want parents to find your pod with the Mamava app, send the new address, a short description, and photos of the pod in its new spot to fulfillment@mamava.com.

The interior outlet isn't working.

Make sure the green LED indicator on the outlet is on. If it's on, but there's no power—or it's off and the unit is plugged in—there may be an issue with the outlet or electrical connection.

The pod is too hot. (Or too cold.)

The temperature of your pod will stay at the temperature of the air around it, give or take a few degrees. Be sure your pod is in a location that's adequately serviced by an HVAC system.

The pod is being misused.

Educate employees and guests that Mamava pods are solely for breastfeeding and pumping.

You need to get in when the deadbolt is locked.

First try this:

Insert the emergency deadbolt key into the center hole of the occupancy indicator dial and turn to "VACANT." Then unlock the keypad with your code or the pre-programmed (2014#). If that doesn't work, use the keys that came with the lock.

Then try this:

You can also access the pod by removing either the center perforated roof panel or, if your pod is an XL, one of the curved side panels. Refer to help.mamava.com for disassembly instructions.

Software Agreement

License Agreement for Mamava Embedded Software Important – please read carefully. This license governs your use of any software embedded or installed in any Mamava equipment (the “equipment”) that is sold or leased to you by Mamava or any third party, excluding any software that is otherwise licensed to you by a separate written agreement between you and Mamava or another third party (any software as delineated in this paragraph, the “software”).

By activating or otherwise using the equipment you are accepting and agreeing to the terms of this license with respect to the software that has been pre-installed on the equipment.

You expressly acknowledge and agree that the software may interface via a cellular data connection, at no additional cost to you, with Mamava’s servers, web site and/or certain mobile applications installed on mobile devices. You agree to be bound by and subject to all published terms and conditions associated with Mamava’s web site and/or any related mobile application used by you or any third-parties that you allow to use the equipment.

You acknowledge and agree that the software may collect and transmit equipment usage data to Mamava. Any data electronically collected by Mamava in connection with the software and/or your use of the equipment shall belong solely to Mamava, and you hereby assign to Mamava any right, title or interest that you may acquire in such information. Mamava’s privacy policy — which can be found at <https://www.Mamava.Com/privacy-policy> — details the information that Mamava collects and what it may do with that information. Mamava’s privacy policy is subject to change from time-to-time at the sole discretion of Mamava.

Subject to your compliance with the terms of this license agreement, Mamava hereby grants to you a limited, non-exclusive license to use the software in machine-readable, object code form solely in connection with the use of the equipment in accordance with terms of this Owner’s Manual. The software may be used only on the equipment in which it was initially installed. You agree that you will not assign, sublicense, transfer, pledge, lease, rent, or share your rights under this license agreement, except that you may permanently transfer all of your rights under this license agreement in connection with the sale or transfer of the equipment, provided that any resulting transferee of the equipment agrees to adhere to the terms this license agreement. You acknowledge and agree that the software is proprietary to Mamava, or its affiliates or licensors and is protected under copyright law, trade secret law and laws governing confidential information.

You acknowledge and agree that all associated intellectual property rights in the software shall remain with Mamava, its affiliates and their licensors. This license does not convey to you title or interest in or to the software. Mamava and its affiliates reserve all worldwide rights not expressly granted under this agreement.

You agree not to reverse engineer, decompile, translate, adapt or disassemble the software, nor shall you attempt to create the source code from the object code for the software. You agree not to hack into, interfere with or try to connect with the equipment’s cellular data connection. You agree that Mamava may, but shall have no obligation to update the software from time-to-time via the equipment’s cellular data connection.

While Mamava has the right to automatically modify, update, or upgrade (in any such instance, “update”) the software at any time, Mamava has absolutely no obligation to provide updates to the software, except as otherwise expressly agreed in writing via a separate agreement between you and Mamava. If and to the extent that Mamava provides any automatic updates, you consent to such automatic updates and agree that the terms and conditions of this license agreement will apply to all such Updates.

YOU AGREE THAT THE SOFTWARE IS PROVIDED “AS IS” AND MAMAVA MAKES NO REPRESENTATIONS OR WARRANTIES REGARDING THE SOFTWARE, INCLUDING, BUT NOT LIMITED TO, REPRESENTATIONS OR WARRANTIES THAT THE SOFTWARE IS FREE FROM ERRORS OR DEFECTS. IN NO EVENT SHALL MAMAVA OR ITS OFFICERS, DIRECTORS, EMPLOYEES, AGENTS, AFFILIATES, OR SUBCONTRACTORS, BE LIABLE FOR ANY SPECIAL, INDIRECT, CONSEQUENTIAL, OR PUNITIVE DAMAGES OF ANY KIND, INCLUDING LOSS OR DAMAGE CAUSED BY THE SOFTWARE.